

Extruder Motor Maintenance

SOURCE:

<https://support.zortrax.com/extruder-motor-maintenance/>

Table Of Contents

- Unloading the Material
- Unplugging the Power Cable
- Material Guide Removal
- Unplugging the Extruder Cable
- Unplugging all Cables from the Extruder PCB
- Unscrewing the Extruder PCB
- Extruder Lower Printed Cover Removal
- Unscrewing the Extruder Aluminum Cover
- Unscrewing the Extruder Motor
- Extruder Motor Removal
- Cleaning the Sprocket Wheel
- Extruder Motor Assembly, part 1
- Extruder Motor Assembly, part 2
- Extruder Aluminum Cover Assembly
- Extruder Lower Printed Cover Assembly
- Extruder PCB Assembly
- Plugging all Cables to the Extruder PCB
- Plugging the Extruder Cable
- Material Guide Installation
- Plugging the Power Cable

The extruder motor is responsible for loading the material into the hotend before and during the printing process. Sometimes residues that remain on the motor sprocket wheel can make it impossible or more difficult for the motor to load the material. If your printer has problems with extrusion, or you can hear a clicking sound coming from the extruder motor when you load the material or print, or if the material gets blocked in the duct in the extruder, the extruder needs maintenance work. This manual gives instructions on extruder motor sprocket wheel cleaning.

The following manual shows the M200 maintenance work. For the M300, these procedures are the same.

Unloading the Material



From the menu choose *Material* and then *Unload the material* option. The extruder should start to heat up automatically. Once the extruder is hot, the motor will start to unload the material.

Unplugging the Power Cable




Turn off the printer and unplug the power cable.

Material Guide Removal




Detach the material guide from the extruder cover. Next, separate the guide from the extruder cable.

Unplugging the Extruder Cable




Detach the extruder upper printed cover and unplug the extruder cable.

Unplugging all Cables from the Extruder PCB




Unplug all the cables from the extruder PCB.

Unscrewing the Extruder PCB



Unscrew the two screws that secure the extruder PCB using a 2mm Allen key. Remove the PCB from the extruder.

Extruder Lower Printed Cover Removal




Remove the extruder lower printed cover.

Unscrewing the Extruder Aluminum Cover




Unscrew the screws that secure the extruder aluminum cover on both sides of the extruder. Separate the cover from the extruder motor.

Unscrewing the Extruder Motor



Unscrew the four screws that secure the extruder motor.

Extruder Motor Removal




Separate the extruder motor from the extruder block.

Cleaning the Sprocket Wheel




Clean the extruder motor sprocket wheel from material remains using tweezers.

Extruder Motor Assembly, part 1




Reattach the extruder motor to the extruder block.

Extruder Motor Assembly, part 2



Secure the motor with the screws. Press the motor to the right side so that the bearing rack is as close to the bearing as possible. Tighten the screws crosswise in the following order: 1-4, 2-3.


Extruder Aluminum Cover Assembly



Reattach the extruder aluminum cover to the extruder and secure it with the screws.


REMEMBER TO SCREW THE ALUMINUM COVER EVENLY ON BOTH SIDES TO AVOID DEFORMATION.

Extruder Lower Printed Cover Assembly




Attach the extruder lower printed cover to the extruder.

Extruder PCB Assembly




Place the extruder PCB in its place and secure it with the two screws.

Plugging all Cables to the Extruder PCB



Plug all the cables in. Remember to arrange the cables so that they don't get damaged, e.g. by wrapping against each other.

Plugging the Extruder Cable



Plug the extruder cable in, and then attach the extruder upper cover to the lower cover.

MAKE SURE THE EXTRUDER CABLE IS PROPERLY PLUGGED IN.

Material Guide Installation



Attach the material guide to the extruder cover. Next, secure the guide to the extruder cable with the material guide clamps.

MAKE SURE THE MATERIAL GUIDE IS PROPERLY INSTALLED IN THE COVER.

Plugging the Power Cable



Plug the power cable in.