

# Workshops 04: Wet Sanding the Model

SOURCE:

<https://support.zortrax.com/post-processing-workshops-04/>

## Table Of Contents

Necessary Tools

Wet Sanding the Headphones

Wet Sanding the Headphone Stand

Reapplying the Primer



## Necessary Tools



For wet sanding you'll need: 800 grit sandpaper, a container with water, a primer, and a rack.

## Wet Sanding the Headphones

Wet the sandpaper with water and smooth the elements one by one until you get a satisfactory result.

Wet sanding will be even more effective once you smooth one small section of the model at a time rather than the whole model at once.





## Wet Sanding the Headphone Stand

Wet the sandpaper with water again and smooth the headphone stand.

As in the case of headphones, wet sand a small section of the headphone stand at a time.







## Reapplying the Primer



In case your smoothing goes a little too far and you sand through the primer to the model, you can easily apply the primer again, let the model air dry, and start wet sanding again.

EPIISODE 04 CAN BE FOUND HERE: [PAINTING THE MODEL](#)