

## How to Install PTFE Tube with Adapter in M300 Dual



Remove the extruder cable from the clamps at the back of the printer.

2 Remove the clamps from the printer's housing.



 $3 \mid \text{Install the Adapter with the PTFE Tube in the printer's housing.}$ 

Insert the extruder cable into the adapter and insert the PTFE tube into the material endstop. Make sure that the tube and cable are connected at a right angle.