# Removing the Print

Table Of Contents

Unplugging the Power Cable

Turn off the printer and unplug the power cable.

Wait about 30 minutes until the platform and the print cool down.

Unplugging the Heatbed Cable

Unplug the heatbed cable from the platform. Both the big and small connectors need to be unplugged.

Platform Removal

Remove the platform from the printer.

Removing the Print

Use the spatula to remove the print.

Remove the print very carefully. Do not point the blade of the spatula towards the platform connectors.

Platform Installation

Put the platform back in the printer and plug the heatbed cable in. Both big and small connectors need to be plugged in.

Plugging the Power Cable

Plug the power cable in.